

Print out template from Adobe Reader. In print settings, under scale make sure "none" is selected. This is a "to scale" drawing and needs to print out as such.

Cut template and red circles out, and trace onto aluminum flashing.

Cut "red circles" out from aluminum flashing. A small pair of scissors should do fine. Also drill holes for small bolts.

Apply stick on screening to opposite side (the side the will wrap under the side with circle cut-outs.

When folding the cone together, I used double sided tape on the inside to hold the two flaps together. I also used masking tape on the outside to help keep everything inline and together. For bolt holes, align the flaps and use a permanent marker to dot where the holes should be on the inside, then drill.

Then just bolt the cone together.

www.PalmCoastBusters.com

