

(4" ADS coupling needed, you can find this in the outdoor section of home depot, near the pool equipment)

The cone needs a sleeve so it can be applied to the slime blower gun.

Cut 3/4" off of the 4" coupling, this will act as your sleeve.

Put the cone on top of the sleeve, use masking tape around the outside to tightly hold the two pieces together.

Use Plumbers GOOP around the inside to bond the two pieces. I applied a couple of coats until I satisfied.

NOTE: You might also want to masking tape 1/2" of the inside part of the sleeve so the GOOP doesn't apply to unnecessary areas. Remember you need this to fit onto the gun.

Let dry outside for 2-3 hours. If it is hot outside the GOOP will dry faster. But keep in mind it takes about 24-48 hours for the GOOP to fully dry.

After 3 hours. Remove tape from outside.

Apply a small amount of GOOP around the outside of the cone/sleeve. Filling in the seam. This will also give a welded look to the seam. Let dry for 3 hours.

Last thing to do is to tape off the circles (you don't want paint messing up the screening) and paint the entire cone using a Metallic Silver Spray Paint.

Then just slip it onto your gun and you are done :)

(If you have trouble fitting the cone onto your gun, using a Dermal tool with a sanding bit and sand around the inside of the PVC sleeve.)

